

Here is a common circumstance which can make it difficult to apply Blue Monster Compression Seal Tape: **Tight Areas**



The challenge is to maintain full tension on the tape without letting go of it.

The video link below will take you to a short demo of how this can be overcome.

Keep in mind this is **not the recommended method if there is full pressure in the system and the leak is "active."**

In that instance revert to the application method recommended in the video on our website.

<https://www.youtube.com/watch?v=Os89K9P1pYY>



